



LED ROCK LIGHT



USER MANUAL




MADE IN CHINA

WARNING


1. The light must be used only for the prescribed purpose. Any uses outside those mentioned in the manual will be considered misuse. The manufacturer shall not be liable for any damage or injuries resulting from misuse. To use the light properly, please closely observe the instructions found in the manual.
2. Keep children away from electrical equipment. Make sure children are under supervision when operating the light kit.
3. Do not use any power supply that outputs any voltage outside of the light's nominal voltage range. Over-voltage can cause irreversible circuitry damage and even fires.
4. Do not put the light in the temperature outside of the operational range.
5. Do not clean your light with harsh detergents. The light is water-proof but not guaranteed to be protected against other chemicals.

INSTALLATION – MOUNTING

Silicone pad installation




Standard silicone pad




30° angled silicone pad
(sold separately)

Fastener mounting



Screw mounting



Bolt mounting


INSTALLATION – WIRING

Standard reference only.

Refer to wiring labels or the packaging first.


2-wire pinout

For: Dimmer switch models
or single-color models



3-wire pinout

For: Dual-color,
non-dimmer switch models



DIMMER SWITCH CONTROLS

For: Single-color LED models


Example: White LED model



A short tap on the button switch
Turns its power on/off.

A long press on the button switch
adjusts its brightness for each
respective color mode.


Power Off Mode



Power On Mode



Lower brightness



Higher brightness




DIMMER SWITCH CONTROLS

For: Dual-color LED models

Example: White + Amber LED model



A short tap on the button switch cycles through color modes, including power-on/off.
A long press on the button switch adjusts its brightness for each respective color mode.



04


DIMMER SWITCH CONTROLS

For: Tri-color LED models

Example: White + Red + Amber LED model



A short tap on the button switch cycles through color modes, including power-on/off.
A long press on the button switch adjusts its brightness for each respective color mode.



05